

TrendsAudio


USB Audio DAC for Linux Fedora System Setting.

1. Connect Linux System USB port.


P1. Please select System>>Administration>>Soundcard Detection




P2. Please go to Settings tap




P3. Please select USB Audio DAC to Default audio card.



P4. please go to Sound test tap, and use the Sound test button to test sound.



P5. If can hear the sample sound. The USB Audio can function now.



P6. All setting ok, can to player to play music.

